


Token Display Wiring Diagram



Installation

Using software CD install Queue Management server software(QMServer), it controls overall token system, it needs JRE to run, QMServer software will automatically install it's own JRE, so that remove/uninstall any previously installed JRE manually.

we have provided one red color card reader type USB device, this is USB lock to this application, insert it into USB port then connect RS232 & 422 converters on remaining USB port as shown on above wiring diagram and then install it's drivers that provided on CD.

After installation you need to configure comport for token display and token machine, to that communicate us on mail: sales@hextek.in, Mobile:8124976497/9444896273